

ECONOMY LAWN CHAIR

The way I do it.

Bil Gowans
250-376-3919
gowansbil@shaw.ca

I use SPF "off the shelf" construction grade lumber.

Make templates.

1. Cut all pieces to length.
2. Angle cut all straight pieces.
3. Bandsaw or Jig saw curved pieces. (keep side legs together while cutting so they match)
 - a. (back leg, back of armrest, armrest support & footstool leg)
4. Drill & countersink .
5. Sand all edges. Don't leave any sharp corners
6. Use Titebond 3 or other outdoor glue. I use **Lepage PL Premium Polyurethane Adhesive**.



7. Assemble front & back leg first. (use a straight edge & square to line up)
 - a. Be sure to use carriage one or two 5/16 X 2 bolts.
8. I use Particle Board screws & (Deck screws for sides), be sure to drill through countersink.
9. Attach front brace and rear inside brace next.
10. Add seat boards.
11. Attach arm rest and armrest braces back and front.
12. Assemble backrest pieces and set into chair.
13. Add final braces.

For additional strength add extra material to the legs.

Most kitchen chairs are 18" wide. This chair is 21" wide.